



Fitment	Part Number
Suzuki Jimny 2018 on	WA57-580

## Install Instructions

**NOTE – Installation is always recommended by a competent technician.**

1. Remove original cross member mounting nuts
2. Hold cross member and remove bolts
3. Install plates to the inside of the original cross member bolts with the crush tubes between them and install the new bolts nuts and washers.
4. Install the cross member to the inside of the plates as seen below.
5. Tighten the nuts and bolts to factory torque settings.

