

# WA57-511K INSTALLATION GUIDE



1. With Raised Suspension installed, mark Vertical Line, 90 degrees to ground.
  2. Remove arms
  3. Remove old bushes
  4. Align the arm on the template - align the 2 bush holes, there are variances between outer arm shapes between year models and between front and rear. Align the front bush with the vertical mark and template as seen below.
  5. Press in the front bush in around 5mm.
  6. Align the rear bush with the template and measure the hole centres from the front bush to the rear bush ensuring it is 149mm.
  7. Press the rear bush in around 5mm and double check the centre measurements is still 149mm, adjust if required.
  8. Press both bushes in fully ensuring they are central and then re-install arms to vehicle.
- NOTE: Bush kit recommended only for lift kits upto 75mm.

